

VOLKTEK

INDY

QUICK INSTALLATION GUIDE



SYSTEM REQUIREMENT

OS

- Windows 10/11 64-bit

Hardware Requirements

- Intel Core i3 (or equivalent) or higher
- Minimum 8 GB RAM (16 GB recommended)
- Minimum 3 GB free disk space
- Ethernet adapter supporting TCP/IP



SYSTEM REQUIREMENT

Software Requirements

- Modern browsers supported: latest versions of Google Chrome, Mozilla Firefox, Microsoft Edge
- .NET 8
- Internet connectivity is required for:
 - Registration and activation
 - Updates and feature upgrades
 - Accessing online help and support



INDY QUICK INSTALLATION GUIDE

Step 1 Install .NET Core SDK

- Click “**dotnet-sdk-8.0.406-win-x64.exe**”

Step 2 Install INDY



- Enter name and email
- LLDP powershell



INDY QUICK INSTALLATION GUIDE

Step 2 Install INDY


- Enter name and email
- LLDP powershell



INDY QUICK INSTALLATION GUIDE


Step 2 Install INDY

- Enter name and email
- LLDP powershell



```
Administrator: C:\Windows\SysWOW64\cmd.exe
--- Network Adapter LLDP Configuration Menu ---
1) Bluetooth Network Connection - Bluetooth Device (Personal Area Network)
   Current LLDP Status: Enabled
2) Wi-Fi - Intel(R) Wi-Fi 6 AX200 160MHz
   Current LLDP Status: Enabled
3) Ethernet - Intel(R) Ethernet Connection (12) I219-V
   Current LLDP Status: Enabled
0) Exit Program

Please select the network adapter number to enable LLDP (0 to exit):
```




INDY QUICK INSTALLATION GUIDE


Step 3 Enable LLDP and Lamungan Slave on Volktek switch

- Enable LLDP
- Enable Lamungan Slave

1) Go to Settings > Network & Internet



2) Click Advanced network settings




INDY QUICK INSTALLATION GUIDE

Step 3 Enable LLDP and Lamungan Slave on Volktek switch

- Enable LLDP
- Enable Lamungan Slave

3) Expand the network interface which you are using in INDY

4) Select the checkbox to turn on LLDP and click OK to save.




INDY QUICK INSTALLATION GUIDE


Step 3 Enable LLDP and Lamungan Slave on Volktek switch

- Enable LLDP
- Enable Lamungan Slave

1) Go to Switch GUI and log in



2) Find Management > Lamungan Slave




INDY QUICK INSTALLATION GUIDE

Step 3 Enable LLDP and Lamungan Slave on Volktek switch

- Enable LLDP
- **Enable Lamungan Slave**



3) Select Enable and then click Apply



INDY QUICK INSTALLATION GUIDE

Step 4 First-time activation


- Click power button, wait for green light, then click Launch Browser
- When login screen appears, username will be the email entered during installation, password is “admin”
- Once successfully logged in, you can start using the system



INDY QUICK INSTALLATION GUIDE

Step 4 First-time activation

- Click power button, wait for green light, then click Launch Browser
- When login screen appears, username will be the email entered during installation, password is “admin”
- Once successfully logged in, you can start using the system



INDY QUICK INSTALLATION GUIDE

Step 5 Start using INDY Basic

- Once successfully logged in, you can start using the system




INDY QUICK INSTALLATION GUIDE

Configure SNMP on Volktek switch

- Enable SNMP
- Configure SNMP trap


For Switch Side: Enable SNMP/LLDP/
Lamungan Functions

- Go to Switch GUI
and log in.




INDY QUICK INSTALLATION GUIDE

Find Management > SNMP



INDY QUICK INSTALLATION GUIDE

Select Enable and click Apply in Configuration



INDY QUICK INSTALLATION GUIDE

Click Community Name to Set Community String

The screenshot shows the VOLKTEK 5100-24GT2GS web-based management interface. The left sidebar menu includes options like System Status, Basic Settings, Advanced Settings, Security, Monitor, Management (with sub-options for SNMP, SNMP Trap, and SNMPv3), Auto Provision, Mail Alarm, Maintenance, and Syslog. The Management > SNMP > SNMP option is currently selected, highlighted with a yellow background.

The main content area displays the SNMP configuration. At the top right are buttons for LOGOUT, SAVE, and ABOUT. Below them is a small graphic showing LED status for ports 1 through 26. The main section is titled "SNMP" and contains two tabs: "SNMP Settings" (selected) and "Community Name". Under "Community Name Settings", there is a table with columns: Community String, Rights, IP Version, Network ID of Trusted Host, and Number of Mask Bit. The "Community String" field contains "public", "Rights" is set to "Read-Only", "IP Version" is "IPv4", and "Network ID of Trusted Host" and "Number of Mask Bit" are empty. Below this is a row with "Apply" and "Refresh" buttons. A "Community Name List" table follows, showing one entry: No. 1, Community String public, Rights Read-Only, IP Version IPv4, Network ID of Trusted Host 192.168.202.0, Number of Mask Bit 24, and Action Delete.

INDY QUICK INSTALLATION GUIDE

Fill these fields. Then click Apply to save data

SNMP

Community Name

Community Name Settings

| Community String | Rights | IP Version | Network ID of Trusted Host | Number of Mask Bit |
|----------------------|--|-------------------------------------|----------------------------|----------------------|
| <input type="text"/> | <input type="button" value="Read/Write"/> <input type="button" value="Read-Only"/> <input type="button" value="Read/Write"/> | <input type="button" value="IPv4"/> | <input type="text"/> | <input type="text"/> |

Community Name List

| No. | Community String | Rights | IP Version | Network ID of Trusted Host | Number of Mask Bit | Action |
|-----|------------------|-----------|------------|----------------------------|--------------------|---------------------------------------|
| 1 | public | Read-Only | IPv4 | 192.168.202.0 | 24 | <input type="button" value="Delete"/> |

INDY QUICK INSTALLATION GUIDE

Configure SNMP on Volktek switch

- Enable SNMP
- Configure SNMP trap

Set SNMP Trap Receiver


- Go to Switch GUI and log in



A screenshot of the 'System Information' page from the Volktek Switch's GUI. The page has a yellow header bar with 'LOGOUT', 'SAVE', and 'ABOUT' buttons. Below the header is a small status indicator showing 'ALM' and 'PORT' status. The main content area is titled 'System Information' and contains a table of system details. The table includes fields such as Model Name (ST100-24G0T2GS), Hostname (ST100-24G0T2GS), Boot Code Version (V1.2.5.50), Firmware Version (V1.0.1.50), Built Date (Wed Apr 12 09:52:47 CST 2023), DHCP Client (Disabled), IP Address (192.168.1.10), Subnet Mask (255.255.255.0), Default Gateway (192.168.1.1), MAC Address (00:0C:29:1A:F4:7B), Serial Number (21000010000000000000000000000000), Management VLAN (1), CPU Loading (76.94%), Memory Information (Total: 127636 KB, Free: 105056 KB, Usage: 17.69%), Current Time (2024-3-1, 17:7:21), System Uptime (55 days, 5 hours, 23 minutes, 26 seconds), DHCPv6 Client (Disabled), IPv6 Local Address (None), IPv6 Default Gateway (None), and IPv6 Global Address (None). A 'Refresh' button is located at the bottom right of the table.

INDY QUICK INSTALLATION GUIDE

Find Management > SNMP > SNMP Trap.



INDY QUICK INSTALLATION GUIDE

Set SNMP Trap Receiver data:

SNMP Trap

Trap Receiver Trap Event Port Trap Event

Trap Receiver Settings

| IP Version | IP Address | Version | Community String |
|------------|------------|---------|------------------|
| IPv4 | | v1 | |

Apply Refresh

Trap Receiver List

| No. | IP Version | IP Address | Version | Community String | Action |
|-----|------------|--------------|---------|------------------|--------|
| 1 | IPv4 | 192.168.3.11 | v2c | public | Delete |

MONITOR, MANAGE, AND SECURE INDY NMS FOR INDUSTRIAL OT SUCCESS!



INDY



Data visualization



Event notification

VOLKTEK

